

Tunable Empty Pipe Field Guide

WHY USE TUNABLE EMPTY PIPE DIAGNOSTIC?

The Tunable Empty Pipe detection provides a means of minimizing issues and false readings when the pipe is empty. This is most important in batching applications where the pipe may run empty with some regularity. If the pipe is empty, this diagnostic will activate, set the flow rate to 0, and deliver a PlantWeb alert. For more information on the functionality of this diagnostic, see page 2.

These parameters can be configured using the following instructions:

| | |
|------------------------------|--|
| Field Comm. Fast Keys | 1, 2, 2, 4 |
| LOI Menu | Diagnostics, Basic Diag, Empty Pipe |
| AMS Tab | Diagnostics |
| Enhanced DD | Configure, Manual Setup, Diagnostics, Empty Pipe |

For more information about customizing the Empty Pipe Parameters, see page 2.

HOW TO SET-UP

1. **Confirm that the Tunable Empty Pipe diagnostic is enabled.**

| | |
|------------------------------|--|
| Field Comm. Fast Keys | 1, 2, 1, 1, Empty Pipe |
| LOI Menu | Diagnostics, Diag Controls, Empty Pipe |
| AMS Tab | Diagnostics |
| Enhanced DD | Configure, Manual Setup, Diagnostics, Enable Diagnostics |

2. **Configure Empty Pipe Parameters.** The Tunable Empty Pipe diagnostic is set at the factory to properly diagnose most applications. If this diagnostic unexpectedly activates, two Empty Pipe parameters can be custom configured to optimize the Empty Pipe diagnostic for the application.

3. **If the transmitter detects Empty Pipe unexpectedly,** see page 3 for troubleshooting procedures.

| Parameter | Default | Additional Notes |
|--------------------------|---------|---|
| Empty Pipe Value | NA | Read-only, unitless number. If it exceeds Empty Pipe Trigger Level for a specified number of updates, then the Empty Pipe diagnostic alert will activate. |
| Empty Pipe Trigger Level | 100 | Empty Pipe Value threshold limit. Configurable between 3 and 2000. |
| Empty Pipe Counts | 5 | Number of consecutive Empty Pipe Value readings above the Empty Pipe Trigger Level required to trigger the Empty Pipe alert. Configurable between 5 and 50. |

Tunable Empty Pipe

TUNABLE EMPTY PIPE

The Tunable Empty Pipe detection provides a means of minimizing issues and false readings when the pipe is empty. This is most important in batching applications where the pipe may run empty with some regularity. If the pipe is empty, this diagnostic will activate, set the flow rate to 0, and deliver a PlantWeb alert.

Enabling the Tunable Empty Pipe Diagnostic

The Empty Pipe diagnostic can be turned on or off using AMS Suite: Intelligent Device Manager, a Field Communicator, or the Local Operator Interface (LOI) as required by the application.

Understanding the Tunable Empty Pipe Parameters

The Tunable Empty Pipe diagnostic has one read-only parameter, and two parameters that can be custom configured to optimize the diagnostic performance.

Empty Pipe Value

Displays the current value for the Empty Pipe Value parameter. This is a read-only value. This number is a unitless number and is calculated based on multiple installation and process variables such as sensor type, line size, process fluid properties, and wiring. If the Empty Pipe Value exceeds the Empty Pipe Trigger Level for a specified number of updates, then the Empty Pipe diagnostic alert will activate.

Empty Pipe Trigger Level

This value configures the threshold limit that the Empty Pipe Value must exceed before the Empty Pipe diagnostic alert activates. The Empty Pipe Trigger Level can be set to a value between 3 and 2000; the default setting from the factory is 100.

Empty Pipe Counts

This value configures the number of consecutive updates that the Empty Pipe Value must exceed the Empty Pipe Trigger Level before the Empty Pipe diagnostic alert activates. The Empty Pipe Counts can be set to an integer value between 5 and 50; the default setting from the factory is 5.

OPTIMIZING THE TUNABLE EMPTY PIPE DIAGNOSTIC

The Tunable Empty Pipe diagnostic is set at the factory to properly diagnose most applications. If this diagnostic unexpectedly activates, the following procedure can be followed to optimize the Empty Pipe diagnostic for the application.

1. Record the Empty Pipe Value with a full pipe condition.

Example

Full reading = 0.2

2. Record the Empty Pipe Value with an empty pipe condition.

Example

Empty reading = 80.0

3. Set the Empty Pipe Trigger Level to a value between the full and empty readings. For increased sensitivity to empty pipe conditions, set the trigger level to a value closer to the full pipe value.

Example

Set the trigger level to 25.0

4. Set the Empty Pipe Counts to a value corresponding to the desired sensitivity level for the diagnostic. For applications with entrained air or potential air slugs, less sensitivity may be desired.

Example

Set the counts to 10

Technical Note

00840-0400-4664, Rev BB

March 2012

Tunable Empty Pipe

TROUBLESHOOTING THE TUNABLE EMPTY PIPE DIAGNOSTIC

The following actions can be taken if Empty Pipe detection is unexpected.

1. Verify the sensor is full.
2. Verify that the sensor has not been installed with a measurement electrode at the top of the pipe.
3. Decrease the sensitivity by setting the Empty Pipe Trigger Level to a value above the Empty Pipe Value read with a full pipe.
4. Decrease the sensitivity by increasing the Empty Pipe Counts to compensate for process noise. The Empty Pipe Counts is the number of consecutive Empty Pipe Value readings above the Empty Pipe Trigger Level required to set the Empty Pipe diagnostic. The count range is 5 - 50, with factory default set at 5.
5. Increase process fluid conductivity above 50 microsiemens/cm.
6. Properly connect the wiring between the sensor and the transmitter. Corresponding terminal block numbers in the sensor and transmitter must be connected.
7. Perform the sensor electrical resistance tests as outlined in the manual.

Tunable Empty Pipe

Technical Note
00840-0400-4664, Rev BB
March 2012

*The Emerson logo is a trade mark and service mark of Emerson Electric Co.
Rosemount and the Rosemount logotype are registered trademarks of Rosemount Inc.
All other marks are the property of their respective owners.*

Standard Terms and Conditions of Sale can be found at www.rosemount.com/terms_of_sale

**Emerson Process Management
Rosemount Flow**
7070 Winchester Circle
Boulder, Colorado USA 80301
Tel (USA) 1 800 522 6277
Tel (International) +1 303 527 5200
Fax +1 303 530 8549

Emerson Process Management
Blegistrasse 23
P.O. Box 1046
CH 6341 Baar
Switzerland
Tel +41 (0) 41 768 6111
Fax +41 (0) 41 768 6300

Emerson FZE
P.O. Box 17033
Jebel Ali Free Zone
Dubai UAE
Tel +971 4 811 8100
Fax +971 4 886 5465

Emerson Process Management Asia Pacific Pte Ltd
1 Pandan Crescent
Singapore 128461
Tel +65 6777 8211
Fax +65 6777 0947
Service Support Hotline : +65 6770 8711
Email : Enquiries@AP.EmersonProcess.com